

Contec

C1



Crystallising Concrete Waterproofing Compound

'HOW TO' INSTRUCTIONS



SLURRY COAT

Remedial repair treatment

1. Scrape and remove damaged surface. Repair cracks and clean surface.



2. Wet surface with water.



3. Prepare slurry mix



Mix 5 parts C1 to 2 parts water



4. Using a concrete brush, apply an aggressive circular motion to coat the concrete.



5. Apply the second slurry coat.



6. Moist cure for 48 hours



SAFETY PRECAUTIONS

Wear rubber gloves and protective clothing. Avoid contact with skin and eyes. Avoid inhaling product dust.

FIRST AID

If poisoning occurs contact a doctor. If effected flush repeatedly with water and wash skin thoroughly.

Contec

C1



Crystallising Concrete Waterproofing Compound

'HOW TO' INSTRUCTIONS



BROADCASTING / DRY-SHAKE

Adding permanent self healing to freshly poured concrete

Ensure the applied Contec C1 powder becomes an integral part of the surface of the concrete by broadcasting the C1 immediately following the initial screed (see photo). The bleed water is sufficient to wet out the Contec C1 and a bull-float should be used to ensure the C1 becomes in contact with the concrete surface while bleed water is present.



COVERAGE:
0.8kg per m²
25kg per 32m²
Protect the surface from hot sun, frost, rain and ponding



SAFETY PRECAUTIONS

Wear rubber gloves and protective clothing. Avoid contact with skin and eyes. Avoid inhaling product dust.

FIRST AID

If poisoning occurs contact a doctor. If effected flush repeatedly with water and wash skin thoroughly.