

POLYCLOTH

**versatile
reinforcing
fabric for
tanking**



Sizes:

Polycloth 25m x 125mm

Polycloth 25m X 1m



1 Apply Fibreflex to surface and lay Polycloth into the corners, smoothed into the wet surface



2 Apply a coat of Fibreflex over the surface of the Polycloth ensuring the coating penetrates the fibres of the Polycloth



3 Repeat the process for the vertical corners



4 Apply a second coat of Fibreflex to the entire area



Roofing



Water features
Retaining walls



Balconies
Gutters



Bathrooms
Laundry

Meets Industry Standards